

## Instructions on Recharging Pressure Tanks

>Once a Year<

1. Turn off power for the submersible pump.
2. Bypass water treatment equipment.
3. Open – cold water faucet.
4. Drain tank, until air is coming out of drain faucet.
5. Close main valve on outlet side of pressure tank.
6. Fill pressure tank with air, until 35 psi on gauge.
7. Turn on power to the submersible pump.
8. Open main valve slowly to bleed out excess air trapped in plumbing.
9. Place water treatment back into service.
10. Close – cold water faucet.
11. Mark on pressure tank, date of recharge.